

**COD. 31174F****Autodiagnostic CAR adapters SET - VER. 2.60****Includes:**

<b>SL31121</b>	3 pin adapter - FIAT/LANCIA/ALFA ROMEO
<b>SL31122A</b>	2 pin adapter - PSA (PEUGEOT/CITROEN)
<b>SL31132A</b>	30 pin adapter - PSA/FIAT
<b>SL31133</b>	10 pin adapter – OPEL / VAUXALL
<b>SL31134</b>	5 pin adapter – FORD
<b>SL31135</b>	3 pin adapter – FORD
<b>SL31136A</b>	2 pin adapter - VOLKSWAGEN GROUP
<b>SL31137</b>	5 pin adapter – SKODA
<b>SL31139</b>	12 pin adapter – RENAULT
<b>SL31140</b>	9 pin adapter - ALFA ROMEO
<b>SL31143</b>	Sample relay to perform actuator test on Monomotronic Bosch (FIAT - LANCIA)
<b>SL31147</b>	12 pin Adapter With Speed Adapter – RENAULT
<b>SL31172</b>	Sample relay to perform actuator test on Monomotronic Bosch 2 <sup>nd</sup> gen. (FIAT - LANCIA)
<b>SL31177</b>	20 pin Adapter – BMW
<b>SL31191</b>	38 pin Adapter – MERCEDES
<b>SL31192</b>	1 pin Adapter – MERCEDES
<b>SL31197</b>	3 pin Adapter – ROVER
<b>SL31240</b>	Kit of samples for diagnostic on FIAT Group Airbags
<b>2303269</b>	1 pin Adapter Kit – VOLVO
<b>SL31129A1</b>	EOBD J1962 adapter
<b>SL31201</b>	Standard EOBD adapter