




Universal transmission jacks Standard Ideal for many undercar jobs. Much more than just a tool for removal and fitting of transmissions. Ideal for handling and supporting exhaust systems, fuel tanks, etc. **Reversible transmission** adaptor with saddle and rubber pad. Hard chrome piston. NAX. 525 Spring loaded lowering system with dead man control. **OM** 1 **Reversible transmission** adaptor improves access when used for jobs other than transmissions. Wide wheelbase for stability during lifting and manoeuvring of heavy loads. Large swivel wheels for easy manoeuvrability. Large transmission Practical fixing points. @MPAC 1 (3)2 (4)


	Model	Max (Kg)	A (mm)	B (mm)	C (mm)	D (mm)	Kg	
1	TJ 300	300	1095	1930	465x465	60	28	
2	TJ 325	325	1170	2020	595x535	80	30	
3	TJ 525	525	1170	2020	595x535	80	32	
4	TJ 1000	1000	1170	2000	595x535	100	38	




adapter.

18

Know-how is the difference











Telescopic transmission jacks



	Model	Max (Ton)	A (mm)	B (mm)	BB (mm)	BBB (mm)	C (mm)	D (mm)	Kg
5	TJ-T 1300	1.3/0.5	1000	2010	1500		760x640	100	65
6	TJ-T 2000	2.0/1.0	800	1910	1600	1240	1050x1050	150	165



YEA

RRA